

6/9/12KW ELECTRICAL DIAGRAM H0020326

K1: Heating switch	E1: DHW Electrical heater
K2: Cooling switch	E2: Buffer tank electrical heater
K3: Reserve	C1: Built-in water pump
K4: Water flow switch	C2: Auxiliary pump or indoor circulation pump
K5: Reserve	C3: DHW auxiliary pump
K6: SG2 contact without power	G1: DHW 3-way valve
K7: PV ready switch	G2: Season 3-way valve(G2L:OFF:Cooling or G2L:ON:heating)
K8: SG1 contact without power	SG1、SG2、H、C、COM: Input point is contact without power
Remarks*: Optional	